

## LEXUS

### ES300

3.0	1997-01	MCV20	ZDP1381.01C		
3.0	1997-01	MCV20	ZDP1381.02	REAR	99-
3.0	1997-01	MCV20	ZDP0642.01C		
3.0	1997-01	MCV20	ZDP0407.01C		
3.0	1997-01	MCV20	ZDP0407.01		
3.0	1997-01	MCV20	ZDP0407.02	FRONT	
3.0	1997-01	MCV20	ZDP0642.01		
3.0	1997-01	MCV20	ZDP0642.02	REAR	-99

### GS300

3.0	1997-05	JZS160R	ZDP0448.02	REAR	
3.0	1997-05	JZS160R	ZDP0444.01C		
3.0	1997-05	JZS160R	ZDP0448.01C		
3.0	1997-05	JZS160R	ZDP0444.02	FRONT	
3.0	1997-05	JZS160R	ZDP0448.01		
3.0	1997-05	JZS160R	ZDP0444.01		

### IS F

5.0	2007-	USE20	ZDP1350.02	FRONT	Can use as alt. Has Wear sensor cut
5.0	2007-	USE20	ZDP1503.02	FRONT	OEM Fitment
5.0	2007-	USE20	ZDP1464.02	REAR	

### IS200

2.0	1999-06	GXE10	ZDP0444.01		
2.0	1999-06	GXE10	ZDP0444.02	FRONT	
2.0	1999-06	GXE10	ZDP0448.01		
2.0	1999-06	GXE10	ZDP0448.01C		
2.0	1999-06	GXE10	ZDP0444.01C		
2.0	1999-06	GXE10	ZDP0448.02	REAR	

### IS250

2.5	2005-15	GSE20	ZDP1386.01C		
2.5	2005-15	GSE20	ZDP1386.02	REAR	
2.5	2005-15	GSE20	ZDP1385.02	FRONT	

### IS300

3.0	2001-06	JCE10	ZDP0444.01C		
3.0	2001-06	JCE10	ZDP0444.01		
3.0	2001-06	JCE10	ZDP0448.01C		
3.0	2001-06	JCE10	ZDP0448.01		
3.0	2001-06	JCE10	ZDP0444.02	FRONT	
3.0	2001-06	JCE10	ZDP0448.02	REAR	

### IS350

3.5	2005-14	GSE21	ZDP1485.02	FRONT	
3.5	2005-14	GSE21	ZDP1386.02	REAR	

### LS400

## LEXUS

4.0	1994-01	UCF20	ZDP0452.01		
4.0	1994-01	UCF20	ZDP0451.01		
4.0	1994-01	UCF20	ZDP0452.02	FRONT	Directional Pads - Cutout to leading e
4.0	1994-01	UCF20	ZDP0451.02	REAR	
4.0	1989-92	UCF10 SERIES	ZDP0295.01		
4.0	1989-92	UCF10 SERIES	ZDP0270.01		
4.0	1989-92	UCF10 SERIES	ZDP0295.02	REAR	
4.0	1989-92	UCF10 SERIES	ZDP0270.01C	FRONT	
4.0	1989-92	UCF10 SERIES	ZDP0270.01C		
4.0	1989-92	UCF10 SERIES	ZDP0270.02	FRONT	